


Valuable technical information



SPARE-PART & MAINTENANCE KITS Model HL2/90

SPERRE's kits of genuine spare-parts include the wear parts you must change when you overhaul the compressor. For example, if you replace a valve, it is strongly recommended to replace the valve gaskets at the same time. With a spare-part kit available, all necessary parts are at hand together with clear installation instructions.



For model HL2/90 following kits are available:

| Description | Part No | Content of kit |
|-------------------------|---------|---|
| Gasket kit | 4120 | All flat gaskets, O-rings, sealing rings, and valve gaskets. |
| Crankshaft | 1403MK | Crankshaft with all bearings, flywheel key and nut, Seeger-rings, endplate and screw. |
| Valve LP | 3036MK | Valves and necessary copper rings and/or gaskets. |
| Valve HP | 3037MK | Valves and necessary copper rings and/or gaskets. |
| Overhaul kit – LP valve | 3036MK2 | Valve plates and gaskets. |
| Overhaul kit – HP valve | 3037MK2 | Valve springs, plates and gaskets. |
| Piston LP | 3356MK | Piston, gudgeon pin with Seeger-rings and piston rings. |
| Piston HP | 3352MK | Piston, gudgeon pin with Seeger-rings and piston rings. |
| Connecting rod | 1424MK | Connecting rod with small- and big-end bearings, oil scoop with set screw. |
| Cylinder LP | 1137MK | Cylinder with gaskets, stud bolts/nuts and fittings. |
| Cylinder HP | 1133MK | Cylinder with gaskets, stud bolts/nuts and fittings. |
| Overhaul kit Routine B | 7935 | All parts needed for 5 000-hours' maintenance: Overhaul kits for valves complete with gaskets and guide rings, piston rings, connecting rod bearings, gudgeon pins, Seeger-rings, gaskets and ventilator. |
| Overhaul kit Routine C | 7965 | All parts needed for 10 000-hours' maintenance: Same as kit B, plus complete valves, crankshaft bearings and seal ring. |

Maintenance kits:

- All necessary parts at hand when you need them
- With clear installation instructions enclosed

Genuine Sperre parts give you peace of mind at sea!

Sperre Industri AS
Tel +47 70 16 11 00
Fax +47 70 16 11 10
E-mail: industri@sperre.com

Sperre Rotterdam BV
Tel +31 180 463 299
Fax +31 180 463 264
E-mail: rotterdam@sperre.com

Sperre Asia PTE LTD
Tel +65 763 63 00
Fax +65 763 18 11
E-mail: asia@sperre.com

**Sole suppliers of
genuine spare parts**